

Your KABLE® Pen “HOW TO” Sheet

INSTALLATION – With hidden screw or with double coated adhesive.

WITH SCREW – Suggested for wood or formica surfaces only.

- (1) Position base
- (2) Drill starting hole approximately 1/4" deep at same angle as pen when in base
- (3) Screw firmly to prevent base from rotating

WITH DOUBLE COATED ADHESIVE –

- (1) Clean area that will accept base (surface to be dry and free of dirt, grease, wax, etc.)
- (2) Position base
- (3) Remove protective backing from one side of adhesive and affix to base
- (4) Remove protective backing from other side of adhesive and press base firmly

HOW TO REPLACE JOGGER REFILLS

- (1) Insert end of paper clip into pen barrel grip-hole **(A)**
- (2) Firmly grip writing tip **(B)** and rotate counter-clockwise until end of paper clip engages Kable lock inside barrel
- (3) Unscrew writing tip and replace refill
- (4) Insert end of paper clip into pen barrel grip-hole **(A)**, rotate clockwise to close

